

# Welcome to eSlate!



# The Buttons



Turn the **SELECT** wheel to highlight your choices.



Press **ENTER** to vote for a selected choice.



Use the **CAST BALLOT** button to cast your ballot.



Use **PREV** to go to the previous page.


Use **NEXT** to go to the next page.



Press **HELP** to get help.

# Select Your Language

1. Turn the **SELECT** wheel until the one language you want of five offered is highlighted in red.



2. Press **ENTER** to make your selection.

# Enter Your Access Code

ACCESS CODE
Código de acesso
<b>4192</b>
Date: 11-07-2000
Time: 15:42:21
Place: Mesa Elementary

Enter Your Access Code

1. Turn SELECT wheel to highlight a digit.

2. Press ENTER to choose that digit.



Access Code



1	2	3	
4	5	6	
7	8	9	
0	Clear Last		

Press HELP for instructions. **Battery**

1. Turn the **SELECT** wheel to highlight the first number of your Access Code.
2. Press **ENTER** to choose that number.
3. Repeat for all numbers of your Access Code.
4. When the last digit in your code has been entered, you will see the first page of your ballot.

# Make Ballot Choices

Council Member	
	Abraham Lincoln
	Alexander Hamilton

Council Member	
	Abraham Lincoln
	Alexander Hamilton

1. Turn the **SELECT** wheel until your choice is highlighted in blue.
2. Press **ENTER**. The box to the left of your choice will turn red to show your vote.
3. The blue highlight bar will move to the next contest title.
4. Continue through the ballot until you have voted all the contests you wish to vote.
5. You may use the **PREV** or **NEXT** buttons at any time to move through the ballot.

# How to Do a Write-in Candidate

Enter Write-In Candidate


Candidate Name

A	B	C	D	E
F	G	H	I	J
K	L	M	N	O
P	Q	R	S	T
U	V	W	X	Y
Z	Back	Space	Accept	Cancel

Press HELP for instructions.


# Review Your Ballot

- ✓ After you have voted all the pages of the ballot, a Ballot Summary page appears, allowing you to review your selections.
- ✓ To change your vote, turn the **SELECT** wheel until the contest you want to change is highlighted, then press **ENTER**. You will return to that contest.
- ✓ You may use the **PREV** and **NEXT** buttons to review your ballot.



**Ballot Summary Page**  
To change a vote, highlight the contest to change and press ENTER.

Contest	Selected
<b>PRESIDENT/VICE PRESIDENT</b>	<b>Harry Browne/Art</b>
UNITED STATES SENATOR	No selections
GOVERNOR	Harriett Tubman
ATTORNEY GENERAL	No selections
MAYOR	No selections
COUNTY JUDGE	No selections



Press PREV for previous page.  
To complete your voting and cast your ballot, press CAST BALLOT.

# Cast Your Ballot

When you are finished voting and reviewing your ballot, press the **CAST BALLOT** button.





# Cast Your Ballot

**Your vote has been recorded  
when you see the waving  
American Flag.**

